

# Multi-use Gazebo LED Spot Light (GCL-GSL-D)

---



## INSTALLING YOUR BATTERIES

Requires 3 x AAA batteries. Batteries are not included with the light.

1. Locate finger grips on back cover of the light. Hold the front of the light in one hand and with your other hand grab the finger grips on the battery compartment cover and rotate in a counter-clockwise direction to open.
2. Insert 3 x AAA batteries into the battery chambers ensuring the + and – polarity of the chambers line up with the + and – polarity of the batteries.
3. Replace the battery cover by securely rotating clockwise.

**IMPORTANT:** Always remove batteries from light when not being used for extended periods.

## OPERATING INSTRUCTIONS

1. Install batteries. See separate instructions above.
2. ON and OFF switch is located in centre of light lens. First push will turn light on. Second push will turn light off.
3. The attachment clip is located on the back of light. Simply push the clip onto your gazebo roof frame.

**IMPORTANT:** Please remove the light from the gazebo before folding up the gazebo frame.

### CARE INSTRUCTIONS:

Use a damp sponge or cloth to remove marks. Allow to dry thoroughly. Never pack away damp, dirty or wet. Only a qualified electrician can service or repair this item.

### MATERIALS:

Plastic with electronic componentry

Made in China:  
Designed & Imported by:  
OZtrail Leisure Products  
71 Charles Ulm Place Eagle Farm QLD 4009  
AUSTRALIA